



Twin Industrial units

Thanks for purchasing one of my kits,
This kit just requires glue.



Firstly, Glue the white window surround to the red brick door section making sure the white looks even from the outside.
Glue the window on and set aside.
Glue the two windows on the red and yellow doors and set aside.

Glue the grey gables to the sides with the sides on the inside,
Let this dry fully.

On the two long red brick sections gently fold on the score lines, On the long strip you will see a fold tab use this tab to glue the shorter section on.

Glue the red and yellow doors to the grey frame, once dry glue the red brick door section in place.

On the long red brick sections make sure the crease lines are folded enough as this will help being glued in place, Run a thin line of glue around the bottom of the grey section also on the red and yellow door tabs and attach the brick section to the bottom of the grey walls. Once happy with position leave it to dry.

apply some glue to the inside roof section and place the roof panel in place, fix the other straight away so they can be positioned correctly, Once dry Cut the roof windows out following the outer black line, Sparingly apply some glue on the inside of the roof just enough to hold the windows in. They should then fit in nice.

Choose where you want the fuse cabinets positioned and glue in place.